Adding A New Genius Radiator Valve

The following explains how to add a new Genius Radiator Valve (Wireless Radiator Valve) to a Genius Hub.



(1) If you have an existing Genius Radiator Valve it will need to be factory reset before it is connected to a Genius Hub.

See here for how to factory reset a Genius Valve

First, take the Genius Radiator Valve to the Genius Hub (the part that is connected to your internet router) so it is within 2 meters of the Genius Hub with nothing in between.

Remove the battery cover. Do this by placing a fingernail at the bottom of the battery cover, pulling the catch up (in the direction of the screen) and compressing the slit next to the catch. The battery cover hinges at the screen end of the valve.



Ensure there are new batteries in the Genius Radiator Valve and they are correctly oriented.

Note: both of the springs are at the top of the valve but one battery points up and the other points down.



Replace the battery cover, starting at the top (nearest the screen). Now the hub needs to get ready to add the device.

On the app tap on Menu, then Settings and then Devices. Now tap on 'Include device' and follow the prompts on the app.

Press and release the middle /o\ button and the screen backlight should quickly flash.

The letters or numbers on the screen of the valve are not important at this point.



The screen backlight should quickly flash, then slowly flash, then stop flashing when the device has included successfully.



On success, the Genius Radiator Valve has been assigned a number, write this number on the side of the device.

The success or failure of the inclusion will be displayed on the app.

Now pick a zone to assign the Genius Radiator Valve to.

See Chapter 14 of the Manual for full guidance on assigning the channel to a zone. To create a new zone to assign it to see step 5 otherwise skip to step 6.

See the 'Create new zone' section under Chapter 14 of the Manual for guidance on how to create a new zone.

To ensure check the device has been correctly assigned open the zone's page, tap "Zone Setup" under the menu and check the channel is listed under "Zone Devices".

Install the Genius Radiator Valve onto the radiator.



Here is a video to show you how to remove a Genius Radiator Valve

Types of valve adapter:

Standard M30

- Screw the short adapter onto the valve body tight (the metal part that the water flows through).
- Make sure that the valve has a flashing 'M' on the screen.
- Screw the Genius Radiator Valve onto the TRV adaptor tight.
- Long press the middle /o\ button until the valve starts to buzz and 'M' stops flashing.



Danfoss RA

- Push the tall adapter on the TRV body and use the hex key to tighten the adapter until the adaptor starts to distort slightly.
- Make sure that the valve has a flashing 'M' on the screen.
- Screw the Genius Radiator Valve onto the TRV adaptor.
- Long press the middle /o\ button until the valve starts to buzz and 'M' stops flashing.

