

Genius Hub Support Knowledge Base

Browse by topic

app assign-device batt
eries boiler communi
cation comparison com
patibility configuration cre
ate-zone dead-node devi
ce devices-page doc
tor dual-channel-
receiver edit-details elect
ric-heating electric-relay
electric-switch erro
rs factory-reset featured
footprint-mode forgotten-
password genius-hub g
enius-motion-sensor g
enius-
radiator-valve
genius-room-
sensor genius-
room-
thermostat genius
-smart-plug group-zone
hot-water-temperature i
nclude-device i
nstallation-manual inte
rnet-connection ip-
address linked-mode login
manual-override mounting
my-house noarchive-
single off-mode offset ov
erride-mode pluglock po
wered-room-thermostat p
re-heat radiator-valve ran
ge-extender remove-
dead-node restart security
sense-mode setup-pages
single-channel-receiver s

Browse by article

Genius User Manual V5

- 0. Contents
- 1. Registering and logging on
- 2. The My House page
- 3. The Zone pages
- 4. Off Mode
- 5. Timer Mode
- 6. Sense Mode (Beta)
- 7. Footprint Mode
- 8. Override Mode
- 9. Linked Mode
- 10. Group Zones
- 11. Devices page
- 12. Setup pages
- 13. Charts
- 14. Adding new devices
- 15. Troubleshooting and issues
- 16. Legal Information

Genius Installation Manual V5

- 0. Install Contents
- 1. Installing the Genius Hub
- 2. Logging onto the Genius Hub
- 3. Installing the boiler Receiver Units
- 4. Installing the Wireless Thermostats
- 5. Installing the Underfloor Receiver Units
- 6. Installing the Electric Heating
- 7. Installing the Smart Plugs
- 8. Installing the Range Extenders
- 9. Installing the Radiator Valves
- 10. Installing the Room Sensors
- 11. Installing the Motion Sensors
- 12. Testing the heating
- 13. Legal Information & Datasheet

Genius Trouble Shooting Wizard V5.9.1

- Doctor - Dual Channel Receiver
 - Adding A New Dual Channel Receiver
 - Re-adding A Dual Channel Receiver
 - Removing a Dead Dual Channel Receiver
 - Fixing the communication to a Dual Channel Receiver
 - Unassigning A Dual Channel Receiver Channel
- Doctor - Electric Relay
 - Adding A New Electric Relay
 - Re-adding An Electric Relay
 - Removing a Dead Electric Relay
 - Fixing the communication to an Electric Relay
- Doctor - Electric Switch
 - Adding A New Electric Switch
 - Re-adding An Electric Switch
 - Reconfiguring an Electric Switch

Featured Articles


- Positioning Guidelines (Smart Plugs and Range Extenders)
- How to - Remove and refit the Genius Radiator Valve
- Genius App & Hub Changelog
- Adjustments you can make with our Genius Hub Devices to fine tune your setup
- Scheduling Genius Smart Plugs
- Re-adding A Single Channel Receiver
- Re-adding A Dual Channel Receiver

Recently updated articles

0. Install Contents
2024-01-17 • updated by Simon Turner • view change
Dual Band Smart Plug (PLG-E): Why are there two nodes on my system?
2024-01-03 • created by April Naoman
Genius Hub Support Knowledge Base
2024-01-03 • updated by Matthew Hart • view change
Positioning Guidelines (Smart Plugs and Range Extenders)
2023-12-21 • updated by Alasdair Woodbridge • view change
How to - Remove and refit the Genius Radiator Valve
2023-12-19 • updated by April Naoman • view change
Positioning Guidelines (Smart Plugs and Range Extenders)
2023-12-18 • updated by April Naoman • view change
Genius App & Hub Changelog
2023-12-14 • updated by Simon Turner • view change
Positioning Guidelines (Smart Plugs and Range Extenders)
2023-12-14 • updated by Matthew Hart • view change
Is my Genius Radiator Valve working correctly?
2023-12-14 • updated by Matthew Hart • view change
The Genius Radiator Valves - General Operation
2023-12-14 • updated by Matthew Hart • view change
Genius Hub R&D Roadmap (2024)
2023-12-12 • updated by Matthew Hart • view change
Genius Hub R&D Roadmap (2024)
2023-12-12 • updated by Simon Turner • view change
Port Forwarding
2023-11-28 • updated by April Naoman • view change
Port Forwarding
2023-11-27 • updated by Simon Turner • view change


mart-plug system-setup t
emperature-hierarchy tes
ting-the-system timer-
mode underfloor-heating
unrestored-unknown-
attachment user-
manual weather-data wi
ring z-wave zone-valve

Browse by device


Device	Related Articles
	Single Channel Receiver • Technical Documents • Controlling a Plinth Heater • 5. Installing the Underfloor Receiver Units • 3. Installing the boiler Receiver Units • Re-adding A Single Channel Receiver • What are Electric Relays?

- Removing a Dead Electric Switch
- Fixing the communication to an Electric Switch
- Re-Adding A Time and Temperature addon
- Reconfiguring a Hot Water Time & Temperature addon
- Adding A New Time and Temperature addon
- Doctor - Genius Hub
 - Login error - the app cannot connect to the Genius Hub (HUB-C)
 - Login error - the Genius Hub is not connected to the cloud (HUB-C)
 - Login error - the Genius Hub software is not responding (HUB-C)
 - Login error - the app cannot connect to the Genius Hub (HUB-B)
 - Login error - the Genius Hub is not connected to the cloud (HUB-B)
 - Login error - the Genius Hub software is not responding (HUB-B)
- Doctor - Genius Radiator Valve
 - Adding A New Genius Radiator Valve
 - Re-adding A Genius Radiator Valve
 - Reconfiguring a Genius Radiator Valve
 - Removing a Dead Genius Radiator Valve
 - Checking that a radiator valve body is working
 - Fixing the communication to a Genius Radiator Valve
 - Re-mounting A Genius Radiator Valve
 - Changing Low Batteries In The Genius Radiator Valve
 - Batteries have leaked in the Genius Radiator Valve
 - Changing Flat Batteries In The Genius Radiator Valve
 - Genius Radiator Valve Offset Temperature
 - Changing Flat Batteries In The Genius Radiator Valve (DA-WRV-E)
 - Changing Low Batteries In The Genius Radiator Valve (DA-WRV-E)
 - Fixing the communication to a Genius Radiator Valve (DA-WRV-E)
 - Adding A New Genius Radiator Valve (DA-WRV-E)
 - Removing a Dead Genius Radiator Valve (DA-WRV-E)
 - Re-adding A Genius Radiator Valve (DA-WRV-E)
- Doctor - Wireless Room Thermostat
 - Adding A New Genius Room Thermostat (HI-WRT-D)
 - Re-adding A Genius Room Thermostat (HI-WRT-D)
 - Reconfiguring a Genius Room Thermostat (HI-WRT-D)
 - Removing a Dead Genius Room Thermostat (HI-WRT-D)


Genius Radiator Valve responding slowly to change in temperature on the app
2023-11-23 • updated by April Naoman • view change

	- Controlling the Single Channel Receiver with the Genius Hub powered off - Removing a Dead Single Channel Receiver - Fixing the communication to a Single Channel Receiver - Adding A New Single Channel Receiver	- Fixing the communication to a Genius Room Thermostat (HI-WRT-D) - Changing Low Batteries In The Genius Room Thermostat (HI-WRT-D) - Changing Flat Batteries In The Genius Room Thermostat (HI-WRT-D) - Batteries have leaked in the Room Thermostat (HI-WRT-D) - Re-adding A Genius Room Thermostat (DA-WRT-C) - Batteries have leaked in the Room Thermostat (DA-WRT-C) - Changing Flat Batteries In The Genius Room Thermostat (DA-WRT-C) - Changing Low Batteries In The Genius Room Thermostat (DA-WRT-C) - Adding A New Wireless Room Thermostat (HO-WRT-B) - Re-adding A Wireless Room Thermostat (HO-WRT-B) - Reconfiguring a Genius Room Thermostat (HO-WRT-B) - Removing a Dead Genius Room Thermostat (HO-WRT-B) - Fixing the communication to a Genius Room Thermostat (HO-WRT-B) - Batteries have leaked in the Room Thermostat (HO-WRT-B) - Changing Flat Batteries In The Wireless Room Thermostat (HO-WRT-B) - Changing Low Batteries In The Wireless Room Thermostat (HO-WRT-B) - Fixing the communication to a Genius Room Thermostat - Adding A New Genius Room Thermostat - Removing a Dead Genius Room Thermostat - Reconfiguring a Genius Room Thermostat
	Dual Channel Receiver - Is my Genius Radiator Valve working correctly? - Technical Documents	- Doctor - Motion Sensor - Adding A New Genius Motion Sensor - Re-adding A Genius Motion Sensor - Reconfiguring a Genius Motion Sensor - Removing a Dead Genius Motion Sensor - Removing the Genius Motion Sensor from Security Mode - Changing Flat Batteries In The Genius Motion Sensor - Changing Low Batteries In The Genius Motion Sensor - Fixing the communication to a Genius Motion Sensor - Doctor- Powered Room Thermostat - Adding a new Powered Room Thermostat - Fixing the communication to a Powered Room Thermostat

- 3. Installing the boiler Receiver Units
- Re-adding A Dual Channel Receiver
- Controlling the Dual Channel Receiver with the Genius Hub powered off
- Adding A New Dual Channel Receiver
- Removing a Dead Dual Channel Receiver
- Fixing the communication to a Dual Channel Receiver
- Unassigning A Dual Channel Receiver Channel
- Why can't I logon to my Genius Hub?
- Doctor - Range Extender
 - Re-adding A Powered Room Thermostat
 - Removing a Dead Powered Room Thermostat
 - Adding A New In Wall Range Extender
 - Re-adding An Existing In Wall Range Extender
 - Removing a Dead Range Extender
 - Fixing the communication to a Range Extender
- Doctor - Room Sensor
 - Adding A New Genius Room Sensor
 - Re-adding A Genius Room Sensor
 - Reconfiguring a Genius Room Sensor
 - Removing a Dead Genius Room Sensor
 - Fixing the communication to a Genius Room Sensor
 - Re-adding A Genius Room Sensor That Depletes Batteries Quickly
 - Changing Flat Batteries In The Genius Room Sensor
 - Changing Low Batteries In The Genius Room Sensor
 - Battery has leaked in a Room Sensor
- Doctor - Single Channel Receiver
 - Adding A New Single Channel Receiver
 - Re-adding A Single Channel Receiver
 - Removing a Dead Single Channel Receiver
 - Fixing the communication to a Single Channel Receiver
- Doctor - Smart Plug
 - Adding A New Smart Plug
 - Re-adding A Smart Plug
 - Removing a Dead Genius Smart Plug
 - Fixing the communication to a Genius Smart Plug
 - Adding A New Smart Plug (PH-PLG-E)
 - Removing a Dead Genius Smart Plug (PH-PLG-E)
- Not Device Related
 - Adding A New Generic Z-Wave Device
 - Checking that an actuator is working
 - Checking that a zone valve is working
 - Checking that the boiler is working
 - Creating a new zone
 - Hot Water On/Off not heating up to temperature
 - Hot Water Temperature zone not heating up to temperature
 - No temperature assigned to zone
 - No temperature reported by the Hot Water Time & Temperature addon
 - No Weather Data for a system
 - Re-adding A Generic Z-Wave Device
 - Zone using the assumed temprature

	- Why isn't my hot water heating up? - Why isn't my radiator or heating up? - Why isn't my wet underfloor heating up? General - Information - Adjusting the offset of the Powered Room Thermostat - Adjusting the responsiveness of the Genius Radiator Valve - Adjustments you can make with our Genius Hub Devices to fine tune your setup - Alexa Genius Hub Smart Home Skill - App changes not saving and app flicking back to what it was set on before - Balancing a Genius Hub system - Battery level hasn't updated since the batteries were changed - Boiler is firing when the heating is turned off - Bringing on the boiler with an Underfloor zone - Can Genius control my boiler? - Can I control my wet Underfloor Heating? - Cannot logon after Genius Hub app update - Cannot logon to the Genius Hub - Can the Genius Hub control Heat Pumps? - Can the system be used in mainland Europe? - Can two people use the app? - Commercial Documents - Connecting the Genius Hub to the Internet through a power line adapter - Controlling an open plan area - Controlling a Plinth Heater - Controlling Electric Underfloor Heating (or Wet Underfloor with a sensitive floor covering) - Controlling lights to mimic occupancy using Genius Room Sensors and Smart Plugs - Controlling lights with Genius Room Sensors and Genius Smart Plugs - Controlling radiators without Genius Radiator Valves - Controlling the Dual Channel Receiver with the Genius Hub powered off - Controlling the heating and hot water manually - Controlling the Single Channel Receiver with the Genius Hub powered off - Controlling the system with no internet - Controlling towel rails/radiators - Device communication time - Differences between the Genius Radiator Valves - Differences between the Genius Smart Plug - Dual Band Smart Plug (PLG-E): Why are there two nodes on my system? - Factory resetting a Genius Radiator Valve - Factory resetting a Genius Radiator Valve (DA-WRV-E) - Factory resetting a Genius Room Sensor - Factory resetting a Genius Smart Plug - Factory resetting an Electric Relay - Factory resetting an Electric Switch - Factory resetting a Powered Room Thermostat
 The diagram shows a white Genius Hub device with a circular logo. Two concentric arcs represent the signal and power ranges. The outer arc is labeled '60m' and the inner arc is labeled '30m'. The word 'HUB' is written above the arcs.	Electric Switch - Technical Documents - Controlling a Plinth Heater 14. Adding new devices 5. Installing the Underfloor Receiver Units 6. Installing the Electric Heating 3. Installing the boiler Receiver Units

- Fixing the communication to a Powered Room Thermostat
- Factory resetting the Genius Room Thermostat
- Factory resetting the Genius Room Thermostat (HI-WRT-D)
- Factory resetting the Wireless Room Thermostat
- FAQs of battery-powered devices
- FAQs of Footprint Mode
- Genius Radiator Valve controlling the temperature with a Genius Room Sensor
- Genius Radiator Valve error codes
- Genius Radiator Valve is making a noise when heating
- Genius Radiator Valve not controlling a radiator properly
- Genius Radiator Valve responding slowly to change in temperature on the app
- Genius Radiator Valves, Room Thermostats and Room Sensors all in the same zone
- Genius Radiator Valve taking a long time to warm up - outflow side of the plumbing
- Genius Radiator Valve turns radiator off when a window is opened
- Genius Smart Plug switched on unexpectedly
- Get a blank screen when loading the app
- Hard Wired Actuators for Thermostatic Radiator Valve Bodies (TRV bodies)
- Hot Water control using a Genius Radiator Valve stops working
- How can you test if the Dual Channel Receiver is faulty?
- How does the system communicate?
- How secure is the system?
- How Temperature Hierarchy works
- How the Genius Radiator Valve controls the temperature accurately
- How to manually control the Dual Channel Receiver when it is disconnected from the Genius Hub
- How to manually control the Single Channel Receiver when it is disconnected from the Genius Hub
- How to - Remove and refit the Genius Radiator Valve
- How to - Reset or change the username / forgot the password
- Hub time is wrong
- If This Then That (IFTTT)
- JK Floorheating - Underfloor heating not coming on when Electric Switch shows a solid red light
- Lockable Manual TRV
- Locking the controls of the Genius Room Thermostat
- Logon to the Genius Hub using the local IP address
- Managing your Support Tickets
- Multiple devices not communicating
- No temperature displayed for Hot Water zone
- Port Forwarding
- Positioning Guidelines (Smart Plugs and Range Extenders)
- Powered Room Thermostat error codes
- Remove old & redundant devices off the Genius Hub
- Restarting the Genius Hub
- Rooms feel like different temperatures
- Scheduling Genius Smart Plugs
- Sockets Compatible with the PlugLock




- Adding A New Time and Temperature add-on
- Technical Documents
- Temperature close to the target temperature but the boiler does not come on or the boiler stays on
- The Beta app has expired
- The charts are slow to load
- The difference between remote, zoned and smart control
- The Genius Radiator Valves - General Operation
- The Single or Dual Channel Receiver (boiler controller) has stopped communicating
- The two Genius Valves Adaptors
- Tips for using the Powered Room Thermostat
- Transferring Devices over to a new Genius Hub
- Turning The Genius Hub Off In The Summer
- Updating your Genius Hub
- Uses of the Genius Room Thermostat
- Using If This Then That (IFTTT)
- Using other heating controls with Genius Hub
- Using other Z-Wave equipment on the Genius Hub system
- Valve Exercise Routine - Reset time of operation
- Videos on installing the Genius Radiator Valve
- Is my Genius Radiator Valve working correctly?
- What are Electric Relays?
- What are In Wall Range Extenders?
- What do I need to add for my JK floorheating system?
- What do the Device Channels mean?
- What to do if a zone is not reaching temperature
- What to do if moving house
- What to do with the Genius Radiator Valve when carrying out maintenance, plumbing or decorating
- When to apply an offset
- Why do I have to enter the username and password each time I use the app?
- Why is my Hot Water not getting up to the temperature?
- Genius App Development Info
- Genius App & Hub Changelog
- Genius Hub R&D Roadmap (2024)
- Testing Procedures
- Checking that the boiler controller is working
- Identifying whether the Genius Radiator Valve or the Radiator itself has a fault
- Is my Genius Radiator Valve working correctly?
- Why can't I logon to my Genius Hub?
- Why isn't my hot water heating up?
- Why isn't my radiator heating up?
- Why isn't my wet underfloor heating up?
- How-to articles
- Troubleshooting articles
- Controlling a Plinth Heater

- Hot Water control using a Genius Radiator Valve stops working
- Genius Radiator Valve taking a long time to warm up - outflow side of the plumbing
- Genius Radiator Valve not controlling a radiator properly
- Adding A New Genius Radiator Valve
- 14. Adding new devices
- Adding A New Genius Radiator Valve (DA-WRV-E)

- [Factory resetting a Genius Radiator Valve \(DA-WRV-E\)](#)
- [Re-adding A Genius Radiator Valve \(DA-WRV-E\)](#)
- [Removing a Dead Genius Radiator Valve \(DA-WRV-E\)](#)
- [Removing a Dead Genius Smart Plug \(PH-PLG-E\)](#)
- [9. Installing the Radiator Valves](#)
- [Genius Radiator Valve error codes](#)
- [Changing Low Batteries In The Genius Radiator Valve \(DA-WRV-E\)](#)

	• Fixing the communication to a Genius Radiator Valve (DA-WRV-E) • Changing Flat Batteries In The Genius Radiator Valve (DA-WRV-E) • Differences between the Genius Smart Plug • Differences between the Genius Radiator Valves • Device communication time • Removing a Dead Powered Room Thermostat • How does the system communicate?



Genius Room Thermostat


- Adjustments you can make with our Genius Hub Devices to fine tune your setup
- 4. Installing the Wireless Thermostats
- How Temperature Hierarchy works
- Differences between the Genius Smart Plug
- Differences between the Genius Radiator Valves
- Device communication time
- Uses of the Genius Room Thermostat

- What do the Device Channels mean?
- How does the system communicate?
- FAQs of battery-powered devices
- Re-adding A Wireless Room Thermostat (HO-WRT-B)
- Re-adding A Genius Room Thermostat (HI-WRT-D)
- Re-adding A Genius Room Thermostat (DA-WRT-C)
- Factory resetting the Genius Room Thermostat (HI-WRT-D)

	• Adding A New Genius Room Thermostat (HI-WRT-D)
	Genius Room Sensor • How Temperature Hierarchy works • Differences between the Genius Smart Plug • Differences between the Genius Radiator Valves • Device communication time • Controlling lights to mimic occupancy using Genius Room Sensors and Smart Plugs

- Controlling lights with Geniuses Room Sensors and Geniuses Smart Plugs
- How does the system communicate?
- The difference between remote, zoned and smart control
- FAQs of battery-powered devices
- Re-adding A Geniuses Room Sensor
- Re-adding A Geniuses Room Sensor That Depletes Batteries Quickly
- Re-adding A Geniuses Motion Sensor

- [Factory resetting a Genius Room Sensor](#)
- [FAQs of Footprint Mode](#)
- [Battery level hasn't updated since the batteries were changed](#)



Genius Smart Plug

- [Dual Band Smart Plug \(PLG-E\): Why are there two nodes on my system?](#)
- [Positioning Guidelines \(Smart Plugs and Range Extenders\)](#)
- [Factory resetting an Electric Switch](#)

- [Adjustments you can make with our Genius Hub Devices to fine tune your setup](#)
- [7. Installing the Smart Plugs](#)
- [Factory resetting an Electric Relay](#)
- [Adding A New Smart Plug \(PH-PLG-E\)](#)
- [6. Installing the Electric Heating](#)
- [Controlling lights to mimic occupancy using Genius Room Sensors and Smart Plugs](#)
- [Controlling lights with Genius Room Sensors and Genius Smart Plugs](#)

- [Factory resetting a Genius Smart Plug](#)
- [Genius Smart Plug switched on unexpectedly](#)
- [Scheduling Genius Smart Plugs](#)
- [Multiple devices not communicating](#)
- [Re-adding A Smart Plug](#)

1. A-C

- [app](#)
- [assign-device](#)
- [batteries](#)
- [boiler](#)
- [communication](#)
- [comparison](#)
- [compatibility](#)
- [configuration](#)
- [create-zone](#)

2. D-E

- [dead-node](#)
- [device](#)
- [devices-page](#)
- [doctor](#)
- [edit-details](#)
- [electric-heating](#)
- [electric-relay](#)
- [errors](#)

3. F-H

- [factory-reset](#)
- [featured](#)
- [footprint-mode](#)
- [forgotten-password](#)
- [genius-hub](#)
- [genius-motion-sensor](#)
- [group-zone](#)
- [hot-water-temperature](#)
- [hub](#)

4. I-N

- [include-device](#)
- [installation-manual](#)
- [internet-connection](#)
- [ip-address](#)
- [kb-how-to-article](#)
- [linked-mode](#)

- [login](#)
 - [manual-override](#)
 - [mounting](#)
 - [my-house](#)
 - [noarchive-single](#)
5. O-R
- [off-mode](#)
 - [offset](#)
 - [override-mode](#)
 - [pluglock](#)
 - [powered-room-thermostat](#)
 - [pre-heat](#)
 - [radiator-valve](#)
 - [range-extender](#)
 - [remove-dead-node](#)
 - [restart](#)
6. S-T
- [security](#)
 - [sense-mode](#)
 - [setup-pages](#)
 - [smart-plug](#)
 - [system-setup](#)
 - [temperature-hierarchy](#)
 - [testing-the-system](#)
 - [timer-mode](#)
 - [troubleshooting](#)
7. U-Z
- [underfloor-heating](#)
 - [unrestored-unknown-attachment](#)
 - [user-manual](#)
 - [weather-data](#)
 - [wiring](#)
 - [z-wave](#)
 - [zone-valve](#)