


# Factory resetting a Powered Room Thermostat

## When to factory reset a Powered Room Thermostat

You may need to reset a Powered Room Thermostat if you are swapping which Genius Hub device is included onto, or if you are trying to clear some of the [error codes](#).



## How to factory reset the Powered Room Thermostat

To factory reset a Powered Room Thermostat:

- Ensure that the Powered Room Thermostat is powered on.
- On the front of the device, press the right and centre buttons down for 20 seconds.
- During the 20 seconds **rES** will be displayed on the screen.
- When **rES** is no longer displayed, the device is factory reset.

## How to add the Powered Room Thermostat to a Genius Hub

The Powered Room Thermostat is now factory reset to a default state, to add it back onto the system again go to the 'Doctor' on the app which is under the 'Main Menu'.

For more information see [this article](#).

- [Transferring Devices over to a new Genius Hub](#)
- [Factory resetting an Electric Switch](#)
- [Technical Documents](#)
- [Adjustments you can make with our Genius Hub Devices to fine tune your setup](#)
- [Factory resetting an Electric Relay](#)