



Device communication time

The battery powered devices are programmed to communicate with the Genius Hub on a schedule (wake-up intervals), or if there is a significant change in temperature, or if occupancy is detected. The time interval for each device to check into the Genius Hub is:


- Genius Radiator Valve (DA-WRV-E) = 10 min




- Genius Radiator Valve = 7.5 min



- Genius Room Sensor / Genius Motion Sensor = 30 min




OR




- Wireless Room Thermostat = 30 minutes




- Genius Room Thermostat = 10 min



OR



If your device is not displaying this time on the Devices page, 'Configure' the device from the Devices page. This will send the correct parameters to the device, over the next hour.



Related Information:

- [Dual Band Smart Plug \(PLG-E\): Why are there two nodes on my system?](#)
- [Positioning Guidelines \(Smart Plugs and Range Extenders\)](#)
- [How to - Remove and refit the Genius Radiator Valve](#)
- [Is my Genius Radiator Valve working correctly?](#)
- [Genius Radiator Valve responding slowly to change in temperature on the app](#)