7. Installing the Smart Plugs

Smart Plugs can be used for 2 different purposes. They can be controlled via the app to switch devices plugged into them, via a schedule. They will boost the signal around the property improving reliability of the system and battery life.





The signal travels in straight lines and the only devices that relay the messages are the Smart Plugs, Electric Switches and the Receiver Units. The signal does not bend or bounce, so when positioning think about how thick the wall is that the signal is going to have to pass through to get back to the Genius Hub. Consider that thick stone or concrete walls may be difficult for the wireless signal to penetrate, so the Smart Plug may need to be positioned in a wall socket, which gives a longer route but through thinner walls.

For the **Genius Radiator Valves**, the Genius Smart Plug (Dual Band) is the only device which relay the messages, and so should be spread throughout the property between the Genius Hub and any Genius Radiator Valves.

If you are using the Smart Plugs to boost the signal, they are often placed in one of 2 configurations:

- 1. In properties with a larger footprint, Smart Plugs are often placed on the upstairs floor as the walls are generally thinner upstairs and the signal goes through floors easily.
- In tall & thin properties the Smart Plugs are often placed centrally on each floor. For more information see: https://docs.geniushub.co.uk/x/dgFd



Do not plug anything into a Smart Plug which needs to remain on all of the time such as a fridge or freezer. The Smart Plugs may intermittently turn off, causing anything that you plug into it to also turn off.

Installing the PlugLock

The PlugLock is used in HMOs and commercial buildings as a tamper-proof option for the Genius Smart Plug.



There are 2 ways to install the PlugLock with either the Smart Plug (Single Band) or Smart Plug (Dual Band):

- 1. (Preferred) If the Smart Plug is being installed into a 1-Gang, Unswitched Socket:
 - a. Unscrew the pattress screws holding the socket into the pattress.
 - b. Install the Smart Plug and fit the PlugLock around the Smart Plug, lining up the PlugLock screw holes with the socket screw holes.
 - c. Re-install the pattress screws through both the PlugLock and socket. This will mean that the Smart Plug can now only be removed by unscrewing the pattress screws.

2. If using a 2-Gang or Switched Socket, they will likely not have screw holes which line up with the PlugLock as there is no standard placement for these, and so:



- a. Install the Smart Plug into the socket
 b. Install up to 3 of the adhesive pads provided and fix these onto the flat sections highlighted in grey in the image above. Remove the paper covers from the visible side.
 c. Carefully line up the PlugLock on the Smart Plug, and firmly push the PlugLock onto the socket.